

HOW TO PROCEED WITH TROUBLESHOOTING

1 VEHICLE BROUGHT TO WORKSHOP

NEXT

2 CUSTOMER PROBLEM ANALYSIS (See page [IN-36](#))

NEXT

3 PASSENGER AIRBAG ON/OFF INDICATOR CHECK (See page [RS-251](#))

NEXT

RS

4 DTCs CHECK (Present and Past DTCs) (See page [RS-254](#))

(a) Check for DTCs.

Result

Result	Proceed to
DTC is output.	A
DTC is not output.	B

B **GO TO PROBLEM SYMPTOMS TABLE**

A

5 DTCs CHART (See page [RS-257](#))

NEXT

6 CIRCUIT INSPECTION

NEXT

7 REPAIR OR REPLACEMENT

NEXT

8 DTC CLEARANCE (Present and Past DTCs) (See page [RS-254](#))

(a) Clear the DTCs.

NEXT

9 DTC CHECK (Present and Past DTCs) (See page [RS-254](#))

(a) Check for DTCs.

Result

Result	Proceed to
DTC is not output.	A
DTC is output.	B

B

Go to step 5

A

RS

10 SYMPTOM SIMULATION (See page [RS-251](#))

(a) Check the passenger airbag ON/OFF indicator condition.

Result

Result	Proceed to
Passenger airbag ON/OFF indicator is operating normally.	A
Passenger airbag ON/OFF indicator (OFF) and SRS warning light come on.	B

B

Go to step 5

A

11 CONFIRMATION TEST

NEXT

END